

Disinfection Procedure

RISK CONTROL PLAN

RCP

- Water Off – There is a risk of contamination.
Tick the Box.
- Write down what steps you would take on the back of RCP.
Photograph both sides of the RCP – attach to Maximo.



Complete Repair

- Use chlorine spray frequently on all newly installed fittings/pipes and tools.
Include chlorine spray bottle in the before and after photographs on Maximo.
Reminder, refresh bottles with new chlorine weekly.



Return Pipe to Service

- Flush until clear.
 - Ensure when taking the sample test that you are testing fresh mains water for accurate results.
Pipes less than 150mm do a “colour” test only.
Pipes >150mm and critical assets, do a digital test.
In all cases take a photograph and attach to Maximo.
- REMINDER: When taking FAC digital tests the results must be above 0.3. If below flush again and retest. If you are unsure of anything, contact your team leader.**
- If result below 0.2 DO NOT return pipe to service, escalate to SDM and Planning Engineer.**